

SEGWAY PT WINTER GUIDE

MAINTENANCE TIPS FOR THE WINTER MONTHS

Summer is over and, for many PT owners, cool weather is on its way. To keep your PT in optimal condition during the cold season, whether braving the elements for a brisk glide or placing your PT in hibernation until spring, complete the checklists below. And remember, for detailed technical and safety related information, always refer to your Segway PT Reference Manual.

Winter Storage

If you plan on storing your PT in anticipation of pleasant gliding weather, do the following:

- Protect your PT from the elements. Store it in a safe environment, with an ambient temperature of at least 10°C or above (optimal are temperatures over 15°C).
- Clean your PT.
- Remove your InfoKey battery.
- Fully charge your batteries.*
- If storing your PT longer than 1 month, remove the batteries – be sure to charge your batteries at least every 3 months.
- If storage temperature is below 0 °C, do not charge your batteries. Instead, bring them into a warm environment (over 15 °C) for charging. Doing so will ensure optimal battery life and performance.
- Inflate your tires to the proper pressure.
- You may want to cover your PT to prevent dust accumulation.

Winter Usage / Spring Prep

If you plan on gliding through the winter, or are prepping your PT for spring,, do the following to maintain optimal performance from your PT:

- When not gliding, we recommend keeping your PT in a warm (over 15 °C), safe environment.
- Clean your PT regularly; take special care to keep mats free of debris.
- Keep a fresh battery in your InfoKey.
- Ensure the Lean Steer is straight, then check the Lean Steer fastener torque; tighten to 11N-m if necessary.
- Keep your batteries charged.* If ambient temperature is below 0 °C, do not charge your batteries. Instead, bring them into a warm (above 15 °C) environment for charging. Doing so will ensure optimal battery life and performance.
- Inspect and inflate your tires to the proper pressure.
- If you get a safety alert soon after you begin gliding in cold weather (below 0 °C), try warming your PT up by bringing it into a warm environment for at least 30 minutes.
- For those who like to ride the PT in the winter, we recommend winter tires Urban Snow. They are offering high security and great comfort in all winter conditions.

Drive carefully and enjoy your ride!

Note

If the above checklists are not followed, you may experience the following performance issues: safety shutdown, resulting in error codes c100 and c108; discharged batteries; speed limiter engagement or stick shake warning; reduced range; steering drift; premature tire wear.

*As with all rechargeable batteries, do not charge near flammable materials

Have more questions? Do you need accessories or spare parts? We are at your disposal!